

**PURPOSE:** To Announce the Rinnai Hydronic Air Handler (AH Series) is Approved for the Vertical: Downflow with Bottom or Side Return Configuration.

### PRODUCT INFORMATION



- Applicable Products: Hydronic Air Handler (AH Series)
- Applicable Models:

With Internal Circulation Pump:	AH083CP, AH084CP, AH125CP, AH166CP, AH206CP
Without Internal Circulation Pump:	AH083P, AH084P, AH125P, AH166P, AH206P

### DETAILS

The Rinnai Hydronic Air Handler (AH Series) has been approved for vertical: downflow with bottom or side (left or right side) return configuration.

In a downflow configuration, the air handler is installed upside down (Figure 1). Air flows in through the bottom or sides of the air handler and flows out the top of the unit (Figure 2).



#### NOTE

- Refer to the “Hydronic Air Handler Installation and Operation Manual” for a complete list of approved system configurations.
- The Vertical: Downflow configuration will be added to the next release of the “Hydronic Air Handler Installation and Operation Manual.”