

The system pump plug (terminals 4, 5, and 6) on both E and Q series boilers will be powered during both calls for Heat and calls for Domestic Hot Water. When a boiler is used for both heating and domestic hot water it is suggested that the system pump be connected to an external relay to ensure it is not in operation during a call for domestic hot water.