

The boiler manuals (Installation and Servicing Instructions) will be changed to replace “vegetable oil” to “mineral oil”.

Manual Number	Manual Name	Page Number
8U514004, 8W514004	Q Manual	Page 30
8U516006, 8W516002	E Manual	Page 31
8U515400, 8W515400	QP Manual	Page 31

The new paragraph will be:

Before putting the boiler into operation fill the condensate trap with 1.27 cups / 300 ml of water. If the boiler will be installed in a high temperature installation such as baseboard with a supply temperature of 160°F or above, fill the condensate trap with mineral oil instead of water.