

Pipe Cover Enclosure (Bottom Plate)

For Use With Rinnai Condensing Tankless Water Heaters
(Please contact Rinnai for Model Compatibility)


Bottom Plate Part Numbers: PCD07-IB-BP, PCD07-SM-BP, PCD07-EW-BP, PCD03-SM2-BP



ITEMS INSIDE PRODUCT BOX

Before installation, please make sure that all parts are located inside the product box. If any items are missing or damaged, contact your local dealer/distributor or call Rinnai Customer Care at 1-800-621-9419.

Item #	Item	Qty
①	Pipe Cover Bottom Plate	1



TOOLS/MATERIALS REQUIRED Phillips head screwdriver

INSTRUCTIONS

Assembly

1. Install the bottom plate during Pipe Cover Enclosure assembly. Position the bottom plate between the right and left panels and bottom frame.
2. Place the front bottom frame completely inside the bottom plate. (Figure 1.)
3. Place the back bottom frame between the slots on the back side of the bottom plate. (Figure 1.)
4. Position the Bottom Plate Assembly between the Left and Right Panels. Insert the side panels between the bottom plate and the bottom of the frame. Fasten the assembly using the screws and washers provided with the Pipe Cover Enclosure. (Figure 2.)

NOTE: The tabs of the bottom plate should appear on the outside of the assembly.

5. Complete assembly according to the pipe cover enclosure installation instructions.

Figure 1 Bottom Plate Assembly




Figure 2 Bottom Plate to Pipe Cover Enclosure

